

TRUSCOインパクトホルダー 対応機種一覧

ホルダー 該当品番 : IHSV IHBK

HIKOKI 電動工具

対応品番

DB12DD (2LS)	DV12DA (NN)	WH18DC (NN)	WH36DD 2XHBSZ
DB12DD (NN)	DV12DA 2BS	WH18DC (NNB)	WH36DD 2XHGSZ
DH12DD (2LSK)	DV12DD (2LS)	WH18DC (NNR)	WH36DD 2XHLSZ
DH12DD (NNK)	DV12DD (NN)	WH18DC 2XPBZ	WH36DD 2XHRSZ
DN18DSL LXPZ	DV18DE (2XPZ)	WH18DC 2XPRZ	WH36DD 2XHYSZ
DN18DSL NN	DV18DE (NN)	WH18DC 2XPZ	WH36DD NNB
DS12DA (NN)	WH12DA (NN)	WH18DDL2 (2LYPK)(S)	WH36DD NNG
DS12DA 2BS	WH12DA 2BS	WH18DDL2 (2LYPK)(Y)	WH36DD>NNL
DS12DD (2LS)	WH12DCA (2LS)	WH18DE (2LC)	WH36DD>NNR
DS12DD (NN)	WH12DCA (2LSB)	WH18DE (NN)	WH36DD>NNY
DS14DBL2 (2LYPK)	WH12DCA (NN)	WH36DA (2XNB)	WHP12DA (2LS)
DS14DBL2 (NN)	WH12DD (2ES)	WH36DA (2XP)	WHP12DA (NN)
DS14DBSL (2LYPK)	WH12DD (2LS)	WH36DA (2XPB)	WHP18DBL (NN)(L)
DS14DBSL (NN)	WH12DD (NN)	WH36DC (2XPBSZ)	WP12VA 100V
DS18DBSL (2LSCK)	WH14DB (2YC)	WH36DC (2XPRSZ)	WR14VE (SC)
DS18DC (2XPZ)	WH14DB (NN)	WH36DC (2XPSZ)	WR14VE 100V
DS18DC (NN)	WH14DDL2 (2LYPK)(B)	WH36DC>NN	WR18DH (2XPZ)
DS18DE (2XPZ)	WH14DDL2 (2LYPK)(L)	WH36DC>NNB	WR18DH (NN)
DS18DE (NN)	WH14DDL2 (2LYPK)(R)	WH36DC>NNR	WR36DH (2XPSZ)
DS36DC (2XPSZ)	WH14DDL2 (NN)(B)		WR36DH (NN)
DS36DC (NN)	WH14DDL2 (NN)(L)		WR36DC
	WH14DDL2 (NN)(R)		WR18DBP
			WR14DBDL
			WR14DBAL

BOSCH 電動工具

対応品番

GDR18V-EC6	GDR18V-200C6	GDS18V-300	GDX18V-200
GDR18V-ECH	GDR18V-200C3	GDS18V-300H	GDX18V-200H
GDR18V-ECN	GDX18V-200C6	GDR18V-210CH	GDS18V-330HC
GDX18V-ECP6	GDX18V-200C3	GDX18V-210C	GDS18V-330HCH
GDX18V-ECPH	GDR18V-200CH	GDX18V-210CH	GDS18V-450HC
GDR18V-160	GDX18V-200CH	GDR18V-200	GDS18V-450HCH
GDX18V-180		GDR18V-200H	GDR18V-220C
			GDR18V-220CH

P a n a s o n i c 電動工具

対応品番

EZ1DD1J14D-B	EZ7443X-H	EZ75A3LS2F-H	EZ75A7X-R
EZ1DD1J14D-R	EZ74A1LS2F-H	EZ75A3X-H	EZ75A8LJ2F-B
EZ1DD1J18D-B	EZ74A1X-H	EZ75A7LF2F-B	EZ75A8LJ2G-B
EZ1DD1J18D-R	EZ74A2LJ2F-B	EZ75A7LJ2F-A	EZ75A8X-B
EZ1DD1N18D-B	EZ74A2LJ2F-R	EZ75A7LJ2F-B	EZ75A9LJ2F-B
EZ1DD1N18D-R	EZ74A2LJ2G-B	EZ75A7LJ2F-H	EZ75A9LJ2F-R
EZ1DD1X-B	EZ74A2LJ2G-R	EZ75A7LJ2F-P	EZ75A9LJ2G-B
EZ1DD1X-R	EZ74A2PN2G-B	EZ75A7LJ2F-R	EZ75A9LJ2G-R
EZ1DD2J18D-B	EZ74A2PN2G-R	EZ75A7LJ2G-A	EZ75A9PN2G-B
EZ1DD2J18D-R	EZ74A2X-B	EZ75A7LJ2G-B	EZ75A9PN2G-R
EZ1DD2X-B	EZ74A2X-R	EZ75A7LJ2G-H	EZ75A9X-B
EZ1DD2X-R	EZ74A3LJ2F-B	EZ75A7LJ2G-P	EZ75A9X-R
EZ1PD1J14D-B	EZ74A3LJ2F-R	EZ75A7LJ2G-R	EZ76A1LJ2F-B
EZ1PD1J14D-R	EZ74A3LJ2G-B	EZ75A7LS2F-B	EZ76A1LJ2F-H
EZ1PD1J14D-Y	EZ74A3LJ2G-R	EZ75A7LS2F-H	EZ76A1LJ2F-R
EZ1PD1J18A1B	EZ74A3PN2G-B	EZ75A7LS2F-R	EZ76A1LJ2G-B
EZ1PD1J18A1R	EZ74A3PN2G-R	EZ75A7LS2G-A	EZ76A1LJ2G-H
EZ1PD1J18A1Y	EZ74A3X-B	EZ75A7LS2G-B	EZ76A1LJ2G-R
EZ1PD1J18D-B	EZ74A3X-R	EZ75A7LS2G-H	EZ76A1PN2G-B
EZ1PD1J18D-R	EZ7544LS2S-B	EZ75A7LS2G-P	EZ76A1PN2G-H
EZ1PD1J18D-Y	EZ7544X-B	EZ75A7LS2G-R	EZ76A1PN2G-R
EZ1PD1N18D-B	EZ7545X-B	EZ75A7PN2G-A	EZ76A1X-B
EZ1PD1N18D-R	EZ7548LS2S-B	EZ75A7PN2G-B	EZ76A1X-H
EZ1PD1N18D-Y	EZ7548LS2S-H	EZ75A7PN2G-H	EZ76A1X-R
EZ1PD1X-B	EZ7548X-B	EZ75A7PN2G-P	EZ7940X-H
EZ1PD1X-R	EZ7548X-H	EZ75A7PN2G-R	EZ79A2LJ2F-B
EZ1PD1X-Y	EZ75A1LS2F-H	EZ75A7X-A	EZ79A2LJ2G-B
EZ7441X-B	EZ75A1LS2G-H	EZ75A7X-B	EZ79A2PN2G-B
EZ7441X-H	EZ75A1LS2GTH	EZ75A7X-H	EZ79A2X-B
EZ7443LS2S-H	EZ75A1X-H	EZ75A7X-P	EZ79A3X-B

マキタ 電動工具

対応品番

DF002GRDX	TD002GDXAP	TD149DRFXW	TP131DRGX
DF002GRDXB	TD002GDXYFY	TD149DZ	TP131DRGXB
DF002GZ	TD002GRDX	TD149DZB	TP131DZ
DF002GZB	TD002GRDXB	TD149DZL	TP131DZB
DF470DRGXB	TD002GRDXO	TD149DZP	TP141DRGX
DF474DRGXB	TD002GZ	TD149DZW	TP141DRGXB
DF484DRGX	TD002GZAP	TD157DRGX	TP141DZ
DF484DZ	TD002GZB	TD157DRGXB	TP141DZB
DF484DZB	TD002GZFY	TD157DZ	TS131DRGX
DF487DRGX	TD002GZO	TD157DZB	TS131DRGXB
DF487DZ	TD003GRAX	TD162DRGX	TS131DZ
FS453DRG	TD003GZ	TD162DRGXB	TS131DZB
HP002GRDX	TD138DRFX	TD162DZ	TS141DRGX
HP002GZ	TD138DRFXB	TD162DZB	TS141DRGXB
HP473DRFX	TD138DRFXL	TD173DRGX	TS141DZ
HP474DRGX	TD138DRFXP	TD173DRGXB	TS141DZB
HP484DRGX	TD138DRFXW	TD173DRGXO	TW004GRDX
HP484DZ	TD138DZ	TD173DX	TW004GZ
HP487DRGX	TD138DZL	TD173DXB	TW181DRGX
HP487DZ	TD149DRFX	TD173DXO	TW181DZ
	TD149DRFXB	TD173DZ	TW300DRGX
	TD149DRFXL	TD173DZB	TW300DZ
	TD149DRFXP	TD173DZO	

マックス 電動工具

対応品番

IW20
IW201
IW201 B2C/1850A
IW161