Fenix TK16 Operation instruction Fully press ON Fully press Slightly press OFF Momentary -on Close Release Mid click 7 click Low High Open 18650\*1/ When the light is on CR123A\*2 click click Turbo Press click 1 sec. Strobe When the light is off Strobe OFF Release **Press**